


































	Form Art. Nr.	Artikel Article	Galileo 2155					
			Domici Linea  10072	Domici Celeste  10066	Domici Menta  10067	Domici Crema  10069	Domici Roseo  10070	Domici Grigio  10071
	2155 4020	Kaffeekanne f. 6 Pers. Coffeepot Nr. 2 1,70 Ltr.						
	2155 4220	Teekanne f. 6 Pers. Teapot Nr. 2 1,20 Ltr.						
	2155 4330	Zuckerdose f. 6 Pers. Cov. Sugarbowl Nr. 2 0,20 Ltr.						
	2155 4420	Milchkännchen f. 6 Pers. Creamer Nr. 2 0,20 Ltr.						
	2155 1835	Eierbecher mit Ablage Egg cup						
	2155 4730	Kaffeetasse Cup and saucer 3 0,20 Ltr.						
	2155 4731	Untertasse Saucer 3						
	2155 4732	Obertasse Cup 3 0,20 Ltr.						
	2155 4707	Espressotasse Cup and saucer 0,10 Ltr.						
	2155 4708	Untertasse Saucer						
	2155 4709	Obertasse Cup 0,10 Ltr.						
	2155 0019	Frühstücksteller Plate flat rim 19 cm						

# SCHIRNDING

MADE IN GERMANY  
BY ARZBERG

	Form Art. Nr.	Artikel Article		Galileo 2155					
				Domici Linea 10072 	Domici Celeste 10066 	Domici Menta 10067 	Domici Crema 10069 	Domici Rosco 10070 	Domici Grigio 10071 
	2155 0019	Frühstücksteller Plate flat rim	19 cm						
	2155 0027	<b>Speiseteller</b> <b>Plate flat rim</b>	<b>27 cm</b>						
	2155 0031	Platzteller Plate flat rim	31 cm						
	2155 0122	<b>Suppenteller</b> <b>Plate deep</b>	<b>22 cm</b>						
	2155 2510	Dessertschale quadratisch Fruit bowl square	10 cm						
	2155 0718	Mülschale Cereal dish	18 cm						
	2155 1020	<b>Terrine</b> <b>Cov. soup tureen</b>	<b>2</b> <b>3,5 Ltr.</b>						
	2155 1620	<b>Sauciere 2 tlg.</b> <b>Gravy boat 2 pcs.</b>	<b>0,50 Ltr.</b>						
	2155 1621	Saucieren-Unterteil Gravy boat stand							
	2155 1622	Saucieren-Oberteil Gravy boat only 1 pcs.	0,50 Ltr.						
	2155 2532	Platte oval Fahne Platter ov.	32 cm						
	2155 2534	<b>Platte oval Fahne</b> <b>Platter ov.</b>	<b>35 cm</b>						
	2155 2524	Beilagenplatte Platter ov.	26 cm						
	2155 2260	Platte quadratisch Platter square	30 cm						
	2155 0722	<b>Schüssel rund</b> <b>Salad Bowl round</b>	<b>22 cm</b>						
	2155 0724	<b>Schüssel rund</b> <b>Salad Bowl round</b>	<b>24 cm</b>						
	2155 5402	Schale rechteckig Platter square	19×16 cm						

 = Spülmaschinenfest  
Dishwasher safe  
Résistant au lave-vaisselle

 = Mikrowellengeeignet  
Suitable for microwave use  
Adapté au micro-ondes