















	Form	Art. Nr.	Artikel Article	Palazzo 2152						
				WeiB 00001	 Pitti 06335					
		2152 3115	Kaffeesevice 21 tlg. Coffee-Set 21 pcs.	6 Personen						
		2152 3253	Teesevice 21 tlg. Tea-Set 21 pcs.	6 Personen						
		2152 3103	Kaffeegedeck Place-Setting 3 pcs.	3 tlg.						
		2152 4005	Portions-Kaffeekanne Coffeepot	Nr. 0	0,30 Ltr.					
		2152 4020	Kaffeekanne f. 6 Pers. Coffeepot	Nr. 2	1,70 Ltr.					
		2152 4205	Portions-Teekanne Teapot	Nr. 0	0,35 Ltr.					
		2152 4220	Teekanne f. 6 Pers. Teapot	Nr. 2	1,20 Ltr.					
		2152 4320	Zuckerdose f. 6 Pers. Cov. Sugarbowl	Nr. 2	0,20 Ltr.					
		2152 4420	Milchkännchen f. 6 Pers. Creamer	Nr. 2	0,20 Ltr.					
		2152 2842	Kuchenplatte rund Cake plate rd.		30 cm					
		2152 2834	Tortenplatte Tart dish		30 cm					
		2152 2844	Kuchenplatte rechteckig Cake plate obl.		33 cm					
		2152 1810	Butterdose eckig Cov. butter dish		250 gr.					
		2152 1835	Eierbecher mit Ablage Egg cup							
		2152 2830	Butterplatte Butter-dish		18 cm					
		2152 4615	Kaffeetasse Cup and saucer	4	0,20 Ltr.					
		2152 4616	Untertasse Saucer	4						
		2152 4617	Obertasse Cup	4	0,20 Ltr.					
		2152 4640	Espressotasse Cup and saucer	0	0,10 Ltr.					
		2152 4641	Untertasse Saucer	0						
		2152 4642	Obertasse Cup	0	0,10 Ltr.					
		2152 4635	Teetasse Tea-cup and saucer	4	0,20 Ltr.					
		2152 4636	Untertasse Tea-saucer	4						
		2152 4637	Obertasse Tea-cup	4	0,20 Ltr.					
		2152 4630	Teetasse Cup and saucer	0	0,15 Ltr.					
		2152 4631	Untertasse Tea-saucer	0						
		2152 4632	Obertasse Tea-cup	0	0,15 Ltr.					
		2152 0019	Frühstücksteller Plate flat rim		19 cm					

 = Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle

 = Mikrowelleneeignet
Suitable for microwave use
Adapté au micro-ondes

SCHIRNDING

MADE IN GERMANY
BY ARZBERG

	Form Art. Nr.	Artikel Article	Palazzo 2152				
			Weiß 00001 	Pitti 06335			
	2152 3204	Etagere 2 tlg. Etagere 2 pcs.					
	2152 3206	Etagere 3 tlg. Etagere 3 pcs.					

Servicezusammenstellungen:


Kaffeeservice 21 tlg.: 1 Kaffeekanne Nr. 2, 1 Zuckerdose Nr. 2, 1 Milchkännchen Nr. 2,
6 Kaffeetassen Nr. 4, 6 Frühstücksteller 19 cm


Teeservice 21 tlg.: 1 Teekanne Nr. 2, 1 Zuckerdose Nr. 2, 1 Milchkännchen Nr. 2,
6 Teetassen Nr. 4, 6 Frühstücksteller 19 cm








Composition of the set's:


Coffee-Set 21 pcs.: 1 Coffeepot No. 2, 1 Cov. Sugarbowl No. 2, 1 Creamer No. 2,
6 Cup and Saucer No. 4, 6 Plate flat rim 19 cm


Tea-Set 21 pcs.: 1 Teapot No. 2, 1 Cov. Sugarbowl No. 2, 1 Creamer No. 2,
6 Tea-cup and saucer No. 4, 6 Plate flat rim 19 cm

 = Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle

 = Mikrowellengeeignet
Suitable for microwave use
Adapté au micro-ondes



	Form Art. Nr.	Artikel Article	Palazzo 2152					
			WeiB 00001	Pitti 06335				
	2152 3016	Tafelservice: Dinner set: 16 tlg. (m. Terrine 1) 6 Personen 16 pcs. (with Cov. Soup Tureen 1)						
	2152 3096	16 tlg. (m. 2 Salats) 6 Personen 16 pcs. (with 2 Sald bowls)						
	2152 0017	Brotteller Plate flat rim					17 cm	
	2152 0019	Frühstücksteller Plate flat rim					19 cm	
	2152 0026	Speiseteller Plate flat rim					26 cm	
	2152 0030	Platzteller Plate flat rim					30 cm	
	2152 0122	Suppenteller Plate deep					22 cm	
	2152 0514	Dessertschale Fruit conical					14 cm	
	2152 0718	Müslischale Cereal dish					18 cm	
	2152 0420	Suppentasse Cream soup C/S 2 hdl.					0,32 Ltr.	
	2152 0421	Suppen-Untere Cream soup saucer					19 cm	
	2152 0422	Suppen-Obere Cream soup cup 2 hdl.					0,32 Ltr.	
	2152 1010	Terrine 1 Cov. soup tureen					2,60 Ltr.	
	2152 1620	Sauciere 2 tlg. Gravy boat 2 pcs.					0,50 Ltr.	
	2152 1621	Saucieren-Unterteil Gravy boat stand					19 cm	
	2152 1622	Saucieren-Oberteil Gravy boat only 1 pcs.					0,50 Ltr.	
	2152 2428	Platte oval Platter ov. rim					30 cm	
	2152 2434	Platte oval Platter ov. rim					35 cm	
	2152 2424	Beilagenplatte Platter ov. rim					24 cm	
	2152 2230	Platte rund flach Platter rd. fl.					30 cm	
	2152 0722	Schüssel rund Salad conical					22 cm	
	2152 0724	Schüssel rund Salad conical					24 cm	

 = Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle

 = Mikrowelleneeignet
Suitable for microwave use
Adapté au micro-ondes

SCHIRNDING

MADE IN GERMANY
BY ARZBERG

	Form Nr.	Art. Nr.	Artikel Article	Palazzo 2152					
				Weiß 00001 	Pitti 06335				
	2152	1801	Salzstreuer Salt shaker						
	2152	1802	Pfefferstreuer Pepper shaker						

Servicezusammenstellungen:


Tafelservice 16 tlg.: 6 Speiseteller 26 cm, 6 Suppenteller, 1 Schüssel 22 cm,
mit Terrine 1 Terrine 2,60 Ltr., 1 Sauciere, 1 Platte oval 35 cm


Tafelservice 16 tlg.: 6 Speiseteller 26 cm, 6 Suppenteller, 1 Schüssel 22 cm,
mit 2 Salats 1 Schüssel 24 cm, 1 Sauciere, 1 Platte oval 35 cm

Composition of the set's:

Dinner set 16 pcs.: 6 Plate flat rim 26 cm, 6 Plate deep, 1 Salad conical 22 cm,
with Cov. Soup Tureen 1 Cov. Soup Tureen 2,60 Ltr., 1 Gravy boat, 1 Platter oval 35 cm

Dinner set 16 pcs.: 6 Plate flat rim 26 cm, 6 Plate deep, 1 Salad conical 22 cm,
with 2 salad bowls 1 Salad conical 24 cm, 1 Gravy boat, 1 Platter oval 35 cm

 = Spülmaschinenfest
Dishwasher safe
Résistant au lave-vaisselle

 = Mikrowellengeeignet
Suitable for microwave use
Adapté au micro-ondes